



## SNAP-ON TRIM INSTALLATION

- \* 8-foot lengths of Snap-on Trim come with the required snap attachments already inserted into the trim. The plastic snap attachment pieces have double-sided tape applied for *initial* application to the wall surface.
- 1 Be certain that the Speakeasy dry erase wallcovering is cut square in the area being covered. The edges of the dry erase will be used as guides for the Trim installation.
- 2 The two vertical, or side pieces, are installed first. These Trim pieces will be cut to be flush with the top and bottom edges of the dry erase wallcovering. After taking measurements, cut the aluminum Trim piece(s) with an appropriate metal blade to insure a clean cut. File or sand edges as necessary to remove any loose metal after cutting.
- 3 After cutting the vertical Trim pieces to length, and confirming the measurements are correct and the vertical line is level, peel off the release paper from the double sided tape and apply the Trim and snap attachment to the edge of the dry erase wallcovering. The side edge of the aluminum Trim should be flush with the edge of the dry erase wallcovering.
- 4 Once this portion of the installation is complete, carefully remove the aluminum Trim from the snap attachments by sliding or pulling it off. The double sided tape should hold the snap attachment in place.
- 5 With the aluminum Trim removed, apply 1/2" to 1" staples between the two legs of the snap attachments to insure they are permanently affixed to the wall surface. Reapply the aluminum trim pieces to the, now permanent, snap attachments.
- 6 Next, the top, or horizontal Trim piece(s) will be applied to fit cleanly between the two vertical side pieces, which have already been installed. The two ends of the top Trim will abut the inside edge of the two side trim pieces.

After determining the length of the top trim piece(s) and cutting to size, confirm it is a good fit by holding the cut piece(s) in place.

**SNAP-ON TRIM INSTALLATION (continued)**

- 7 Remove the release paper from the double sided tape and apply the Trim to the top edge of the dry erase wallcovering. As before, remove the aluminum Trim, staple the snap attachments in place, and then reapply the aluminum trim.
- 8 If a Marker Tray is to be installed, it should be the last step in the installation process. The Tray should be installed along the bottom edge of the dry erase. Just like the top trim piece, the Marker Tray should fit cleanly between the two side trim pieces, and run along the bottom edge of the dry erase wallcovering.

To guarantee the proper support for the Tray, you must locate and mark the wall support studs where the Tray will be attached to the wall.

The Marker Tray is provided with a strip of double face tape on the back edge as a temporary aide enabling the installer to position and hold the tray in place for the permanent attachment process with self tapping screws.

Once a level line has been established, using the bottom edge of the dry erase wallcovering as a guide, remove the release paper from the double face tape and attach the Tray to the wall. Next use the provided 1 1/2" long self-tapping screws, going through the back rail of the Tray into the wall studs for proper support.

- 9 When installing black Trim or Tray, use a black permanent marker to touch-up any areas where paint damaged has occurred.

**STOP IF ANY PROBLEMS ARE ENCOUNTERED AT ANY POINT DURING INSTALLATION. CONTACT YOUR SPEAK EASY REPRESENTATIVE IMMEDIATLEY.**