



CORK TRIM INSTALLATION INSTRUCTIONS

Parts included with 8 foot long Cork Trim piece:

- 1 (2) End Stops with one 1.25" attachment screw for each
 - 2 (3) Grommets and 1.25" screws for attachment every two feet.
This means strip will have exposed screw heads every two feet.
- Cut Cork Trim piece to size, if necessary.
 - Determine level line for proper installation
 - Secure one end with End Stop and screw.
 - Bring Cork trim piece to predetermined level line, and secure opposite end.
 - Use additional screws and grommets to secure balance of tack-strip in two-foot increments.

Press grommet into the cork facing, so that the grommet is roughly flush with the cork surface. Place self-tapping screw through the grommet and screw through the cork and aluminum extrusion into the substrate.